



Step 1: Head install

Place the metal "tool head" on to the wood handle and line up the holes. Note: On rare occasions, if the holes do not line up, gently tapping with a hammer, or against the ground, should complete the process. If not, a 1/4" drill bit can be used to help align the holes.



Recommended Tools

Two Philips Screwdrivers

Step 2: Hardware

Using hardware supplied with the tool head, insert the long barrel section through the hole. Thread on the shoulder bolt from the other side. Tighten the post binding bolt from both ends using a Philips screw driver. Optional: thread lock can be applied to prevent the screw from loosening over time.