

INSTALLATION INSTRUCTIONS FOR 7.5' DEER FENCE

- Using a 10' post, insert posts 2 ½' into the ground.
- Space posts not more than 15' apart.
- Reinforce corners and end posts with support wire, rods or posts installed at 45 degree angle to the ground.
- Pull the fence tight to create tension while attaching to the posts.
- Use permanent plastic zip ties to attach the fence to the posts.
- Weave plastic or plastic coated tension wire through both the top and bottom edges of the fence.
- Attach the wire to the posts.
- Secure the tension wire to the fence edges with clips or hog rings every three feet.
- Place 8" sod staples on the bottom edge of the fence to secure the edge to the ground.
- Attach white ribbons to the fence every 10', 4' above the ground.

The above installation instructions were obtained from an independent deer fence installation company and have not been tested by any Tenax employees. For further assistance with installation, please contact a professional fence installer.