

EST. 1885

A.M. LEONARD

HORTICULTURAL TOOL & SUPPLY COMPANY

AGS2 - A.M. Leonard Garden Scooter with Flat Free Tires

Step 1) Remove Components from Box

For your convenience the Leonard Garden Scooter is mostly preassembled. The main loose components in the box are the preassembled scooter, the tractor style seat, the handle, the basket, and a small bag of hardware. Please place the components on a flat work surface and make sure you have everything prior to beginning assembly. If anything is missing or you have any questions, please contact us at 800-543-8955



Step 2) Seat Installation

Attach the seat by threading the seat post clock-wise into the welded base. Once the seat has been threaded through the base, push the supplied cotter pin through the seat post hole and bend pin back around post. Press tightly to post with pliers.



Parts List	
Item#	Description
AGS1002	Tractor Style Seat
AGS1003	Black Poly Tray
AGS2004	Flat Free Wheel
AGS2006	Wire Basket
AGS1007	Handle
AGS2009	Rear Axle
AGS2010	Handle & Seat Hardware
AGS2011	Rear Axle Spacers
AGS2012	Steering Bearing Set



Step 3) Handle Attachment

Attach the steering handle to the steering assembly arm with the provided bolt, washer, and nut as shown. Hold hex bolt secure with pliers and tighten nut with adjustable wrench or socket driver.



Step 4) Basket Installation

The installation of the wire basket doesn't require tools. Simply slip the basket bracket through the frame on a diagonal, then level and secure the basket bracket to the scooter frame as shown. The basket will accommodate a TubTrug or 5 gallon bucket for additional capacity.



Thanks again
for your
purchase!