



**Assembly instructions for
#2448WG - 2460WG**



Box Contents:		
Qty	Item#	Description
4	MW410	Pneumatic 10" Wheel Assemblies
4	CP114	Axle Cotter Pins
4	WA58	Axle Washers

Assembly Instructions

- 1) Wagon frame is partially assembled. Remove cart frame from package and position upside down with deck flat to work surface.
- 2) Slide wheels onto axles, then axle washers. Next slip the cotter pins through axle holes, bending ends with plier
- 3) If handle is not pre-installed. Line up handle bracket with hitch tube and install provided hex bolt, washer, and nut. Secure using 9/16" wrench and 9/16" socket driver, or adjustable wrench.
- 4) Check adjustment of the pre-installed undercarriage bolt. Nut should be snug yet allow smooth movement of handle. If necessary, adjust using 3/4" wrench and 3/4" socket driver, or adjustable wrench.
- 5) Check tire inflation per the psi rating listed on tire and inflate if necessary.