



LEONARD 7" STIRRUP HOE ASSEMBLY INSTRUCTIONS

A.M. Leonard Inc. Piqua Ohio. | 800-543-8955 | amleo.com



Components of Stirrup Hoe

Note: Your Stirrup Hoe components may have been shipped separately. If you don't receive all components within a couple days of each other, please contact customer service at 800-543-8955 or your sales rep.

Recommended Tools

Philips Screwdriver and an 8mm wrench.

Step 1: Head install

Place the metal "tool head" on to the wood handle and line up the holes. Using hardware supplied with the tool head, insert the long barrel section through the hole. Thread on the shoulder bolt from the other side. Tighten the post binding bolt from both ends using a Philips screw driver. Tip: Apply a small amount of thread lock to the threads. Note: If the holes of the tool head and wood handle do not line up, a drill with 1/4" bit can be used to help align the holes.



Step 1: Blade Install

***Caution, blade is very sharp!**
Align holes on the side of the blade to the holes on the side of the tool head, mount the blade one side at a time to the outsides of the tool head. Insert the pan head Philips screws and thread on the lock nuts finger tight. Carefully bend the blade to line up the holes on the other side of the tool head and fasten with hardware. Once all four blade bolts are in place, fully tighten the blade bolts using an 8mm wrench and a Philips screw driver.

