

BCH60 - A.M. Leonard Trailer Hitch Attachment Installation Instructions



Step 1)

The Trailer Hitch is a fully welded assembly and comes ready to install to the #BCU22 Receiver Bracket.



Step 2)

The end set of welded trailer hitch brackets, with offset hole, attach to the lowest hole in the receiver tube. Position the brackets on each side of the receiver, align hole, and install a 3" Bent Clevis Pin and Clip.



Step 3)

Tip the cart backward until the upper hole in the Receiver Tube is aligned with top set of welded brackets and install another 3" Bent Clevis Pin and Clip. Keep area between Receiver Bracket and Hitch Bracket Clear.



Step 4)

The 22 Series Cart is now in transport mode. Connect to your utility vehicles drop pin hitch with the provided 4" Bent Clevis Pin and Clip.



Step 5)

To load and unload materials, simply remove the top pin to level the cart. Then tip the cart back and re-pin for transport.

Hardware Included

Qty	Item#	Description
2	58PIN3	3" Bent Clevis Pin
1	58PIN4	4" Bent Clevis Pin
3	58CLIP	5/8" Hairpin Clip

Attention:

- When tipping the cart back into the top hitch bracket, keep this area clear, potential pinch point.
- Hold and control cart handles when removing the top pin to unload materials.
- Off Road slow speed use only, less than 5mph