

EST. 1885

A.M. LEONARD

HORTICULTURAL TOOL & SUPPLY COMPANY

*BCT39 - A.M. Leonard
T-Bar Attachment
Installation Instructions*



Step 1)

Slide the 1-1/4" round handle tube through the large top hole in the square tube until the welded washer is flush to the tube.



Step 2)

Slip the locking collar over the opposite side of handle and slide the collar until it contacts the square tube. Tighten the locking collar with an Allen wrench.



Step 3)

Wipe each side of round handle clean with a wet cloth and dry. Install the hand grips to each end of round tube. The fit is very snug. Start the grip onto the steel tube by hand and push on with your palm. A rubber mallet can be used to tap the grips into place completely.



Step 4)

Slip the 2" Plastic Cap into the top of the square tube at T-Handle end. The cap is held in place by a pressure fit. Push the cap firmly or tap with a rubber mallet.



Step 5)

The T-Bar is now ready for use. Simply insert into the #BCU22 Cart Receiver Bracket and secure into place with the bent clevis pin and clip included with Receiver Bracket #BCU22.



Hardware Included

Qty	Item#	Description
2	22GRIP	Hand Grips
1	COLL114	Locking Collar
1	SQCAP2	2" Square Tube Cap