

EST. 1885

A.M. LEONARD

HORTICULTURAL TOOL & SUPPLY COMPANY

BCU22 - A.M. Leonard Receiver Bracket Assembly for 22 Series Carts

Step 1)

Position the 22LE, 22GP, F22LE, or F22GP Cart face down on a flat work surface.



Step 2)

Place the Receiver Bracket Assembly on top of the tubular cross brace and axle housing. The two sets of receiver holes, closest to each other, should be positioned toward the top of the cart. Center the receiver bracket on the cart width.



Step 3)

Slide a U-Bolt around cross brace tube and through the two bracket plate holes. You may need to lift up slightly on the receiver bracket while installing the U-Bolt. Install washer and lock nut, tighten by hand only at this step.



#BCU22

Step 4)

Install the remaining three U-Bolts, attaching receiver bracket plates, at cross brace and at axle housing. Once all washers and nuts are installed, tighten completely.



Step 5)

The receiver bracket is now ready for use. A bent clevis pin with hairpin clip is included with the #BCU22 Receiver Bracket to quickly install the Swivel Caster and T-Bar Cart Attachments to top receiver hole.

Hardware Included

Qty	Item#	Description
4	UB516	5/16" U Bolts
8	WASH516	5/16" Washer
8	RLN516	5/16" Lock Nut
1	58PIN3	5/8" x 3" Bent Clevis
1	58CLIP	5/8" Hairpin Cotter Pin