



**Assembly instructions for
#2448LW**



Box Contents:		
Qty	Item#	Description
2	MW480	Pneumatic 16" Wheel Assemblies
2	WASH1	Washers for 1" Axle
2	ERING1	E-Ring for 1" Axle

Assembly Instructions

- 1) Position cart frame on a flat work surface.
- 2) Slide wheels onto short axles followed by axle washers.
- 3) Install e-rings into axle grooves, easiest done by placing open end of e-ring in groove, then squeezing e-ring against axle with large plier.
- 4) Check tire air pressure per the recommended tire pressure indicated on the tire. Inflate as needed.