



**Assembly instructions for
#2460EX**

Box Contents:		
Qty	Item#	Description
2	MW480	Pneumatic 16" Wheel Assemblies
1	2460EXAX	Cart Axle 1" x 24-3/4"
4	WASH1	Washers for 1" Axle
2	ERING1	E-Ring for 1" Axle
8	TB516X1	Bolt 5/16" x 3/4"L for Handle
8	WASH516	Washer 5/16"
8	NLN516	Nylon Lock Nut 5/16"

Suggested assembly tools: Large Phillips Screw Driver, 1/2" socket driver, 1/2" wrench, large plier

Assembly Instructions

- 1)** Remove contents of box and make sure you have all parts from above list.
- 2)** Position cart frame upside down with cart deck flat to work surface.
- 3)** Slide axle through the axle housing and center the axle in housing. Install axle washer, then wheel, then 2nd washer for each side. Finish by installing e-rings in axle grooves, easiest done by placing open end of e-ring in groove, then squeezing e-ring against axle with large pliers.
- 4)** Turn cart frame assembly over onto wheels.
- 5)** Position the welded handle plate under the cart deck and line up holes. Slip round head bolt through the deck and handle plate. Install flat washer and hand tighten lock nuts until all bolts are installed. Tighten using 1/2" socket driver and large Phillips screw driver.
- 6)** Check tire inflation per the psi rating listed on tire and inflate if necessary.