


SC-EXW18/EXW27

SPARE PARTS DIAGRAM



1. End Cap for Bottom Pipe
2. End Cap Holding Screw
3. Bottom Grip Set
(Includes Grip and Joint Case)
4. SP-EXW312 Inner Pipe (Without Blade Holder)
5. SP-EXW304B Joint Case for SC-EXW27
Joint Case for SC-EXW18 (**Special Order**)
6. SP-EXW305 Bolt & Nut for Blade Holder to Pipe (1 pc. Each)
7. SP-EXW306 Blade Holder (Right)
8. SP-EXW307 Blade Holder (Left)
9. SB-EXW308 Blade Holding Bolt/Nut (1 pc. Each)
10. Plastic Grip only for the Bottom Pipe
11. End Cap for Inner Pipe
12. Screw for Joint Case (2 pcs.)
13. SB-EXW1 Replacement Blade

*All highlighted items are available from inventory.
All others are available by Special Order.*