



NASH-2.0 SPARE PARTS DIAGRAM AND LIST




Diagram	Part #	Description	Pic	Diagram	Part #	Description	Pic
1	SP-NASH-1	Blade set		13	SP-NASH-13	Screw/washer attaches blade to pipe	
2	SP-NASH-2	Blade bolt/nut		14	SP-NASH-14	Handle lock	
3	SP-NASH-3	Handle set		15	SP-NASH-15	Handle center bolt	
4	SP-NASH-4	Replacement pipe (2m)		16	SP-NASH-16	Washer for handle center bolt	
5	SP-NASH-5	Steel wire set (2m)		17	SP-NASH-17	Handle mounting screw	
6	SP-NASH-6	Rod to handle connector		18	SP-NASH-18	Support grip	
7	SP-NASH-7	Nut for steel wire		19	SP-NASH-19	Wingnut for support grip	
8	SP-NASH-8	Hook / collar plate		20	SP-NASH-20	Plate nut for support grip	
9	SP-NASH-9	Pipe collar		21	SP-NASH-21	Bracket for support grip	
10	SP-NASH-10	Steel wire spring		22	SP-NASH-22	Assembly screw for support grip	
11	SP-NASH-11	Bolt attaches handle to internal wire		24	SP-NASH-24	Handle spring, bolt, washer, and rivet*	
12	SP-NASH-12	Holding ring		25	SP-LA-1	Holding ring pliers	