Instructions for adjusting watering pattern:

Refer to Illustrations 1 and 2.

Illustration 1 - Spray Pattern and Distance Coverage:

Distance coverage can be adjusted and spray pattern altered by any one of the following adjustments.

Turning the water pressure up or down at the faucet:

Turning the diffuser pin **(E)** clockwise to intersect the water stream results in a gentle misty spray pattern. (For newly seeded lawns)

Turning the deflector **(F)** down to meet the water stream, will result in lower spray patterns. (For under trees)

Illustration 2 - Full or Part Circle Coverage:

This sprinkler adjusts to water a full circle or any segment from 30° to 360°.

For full circle watering coverage: Flip wire clip in "Up" position (A)

For part circle watering coverage: Wire clip stays in "Down" position (B) and should be between collars (see Illustration 2). Rotate the upper and lower collars (D) to achieve the desired area of coverage (C).

