


# Andrews®

## REPLACEMENT

## D-RING/COUPLING ASSEMBLY

### for Andrews® 2-Tube Sprinkler & Soaker

#### COUPLING ASSEMBLY INSTRUCTIONS



To remove old coupling, first remove rubber washer, then simply shove blunt end of pencil through coupling from the sprinkler side and dislodge D-rings. To install coupling on the 2-tube sprinkler, be sure that end of plastic is cut off square. Then, with plastic folded at the center seam, smooth side in, perforated side out, slide coupling onto plastic about six inches. Now, insert one D-ring into each tube of plastic, making sure that rounded edge of D-ring, or the edge having small rounded point, goes into the tube first (Fig. 1). Grasp coupling in one hand (Fig. 2) and gently pull plastic and D-rings into coupling so that D-rings and plastic wedge snugly in tapered neck of coupling. Plastic should be flush with the top of D-rings (Fig. 3). Insert rubber washer.

- A. Rubber washer.
- B. Plastic should be flush with top flat edge of D-rings.
- C. D-rings holding plastic in tapered neck of coupling.
- D. Sprinkler folded holes out, smooth side in.

Manufacturing in the U.S.A. since 1945

## A.M. Andrews Co.

4621 S.W. Beaverton Highway  
Portland, Oregon 97221  
(503) 244-1163